



1. Insert the clip on one side of the transom.



2. Pull the clip and extend the clip to the other side of the transom.



3. Ensure the end of the clip is hooked into the hole at the bottom of the plank.



4. Push the plank upward to test whether the plank is securely fastened with the clip. Repeat the same steps on the other side of the plank.

Keep your planks securely locked.



EASY INSTALLATION
WIND RESIST PLANK CLIP